

USER MANUAL

LTSA LTMA Applicators





Contents

Please note! -3

General Information - 3 Validity of this manual and required compliance - 3 How information is represented - 4 Safety instructions - 5 Warning symbols on the machine - 6

Product description -7

Intended use -7 Designation & Appearence -8 Functionality -9 Technical data -10 System requirements XLP 504 with LTSA -12 System requirements XLP 514 with LTMA -14 System requirements XLP 604 with LTMA -16

Commissioning - 17

XLP 504: Installing conversion kit LTSA -17 XLP 514: Installing conversion kit LTMA -20 XLP 504/XLP 514: Installing LTSA/LTMA -23 XLP 604: Installing LTMA -24 Settings in the parameter menu -25 Setting the applicator home position -29

Operation / Malfunctions / Cleaning -31

Operation - Replacing the pressure plate - Remedying malfunctions - Cleaning -



Please note!

GENERAL INFORMATION

Validity of this manual and required compliance

Contents

The complete operating manual for the applicators LTSA and LTMA consists of the following parts:

Manual	Target group	Medium	Availability
User manual	Operating per- sonnel		NOVEXX Solutions website www.novexx.com
Service manual	Service person-	PDF file	NOVEXX Solutions Partner Portal
Spare parts catalogue	nel		www.novexx.com

The present *user manual* refers exclusively to the applicators LTSA and LTMA. It is intended to help in proper installation, operation and adjustment of the applicator.

For technical questions not covered in this user manual:

- ▶ Follow the instructions of the service manual for the applicator and for the applied printer or
- ▶ Request a service technician from our sales partner.

NOVEXX Solutions customer service department is available especially for configuration settings and malfunctions.

Liability

NOVEXX Solutions reserves the right:

- To make changes in design and components, and to use equivalent other parts than those specified in line with technological progress.
- To change information in this manual.

Any obligation to extend these changes to machines previously delivered is excluded.

Copyright

NOVEXX Solutions retains all rights to this manual and its appendices. Reproduction, reprint or any other type of duplication, including parts of the manual, are permitted only with written approval.

Manufacturer

Novexx Solutions GmbH Ohmstrasse 3 D-85386 Eching, Germany Tel.: +49-8165-925-0 Fax: +49-8165-925-231 www.novexx.com



 $\|$

How information is represented

Explanation of symbols

To enhance readability and make information easier to find, different types of information are identified:

- Instruction with no order of tasks assigned
- 1. Numbered instructions introduced by preceding text
- 2. The specified order must be followed!
 - Special note for action that must be performed.
- Enumeration of features
- Other feature



The Experts symbol identifies activities that are reserved exclusively for qualified and specially trained personnel.

Warning Notes

Warning notes are specially highlighted::



WARNING!

Warning notes with the signal word WARNING refer to risks that can result in severe or fatal injuries! The note contains safety measures to protect affected persons.

Instructions must be followed without exception.

CAUTION!

Warning notes with the signal word CAUTION refer to risks that can result in property damage or personal injury (minor injuries). The note contains instructions for preventing damage.

Instructions must be followed without exception.

Illustrations

Illustrations appear in the text where required. References to the illustrations are shown in brackets, if necessary (see table).

Reference to illustration	Application
none	Only one illustrationReference to the illustration is obviousNo position number in the illustration
(A)	Only one illustrationReference to the illustration is obviousPosition number in the illustration
(see fig. above)	Several illustrationsNo position number in the illustration
(see fig. above, pos. A)	Several illustrationsPosition number(s) in the illustration

Table 1: Different references to illustrations.



Parameters

Parameters in the parameter menu are represented in the format Menu name > Parameter name in grey type.

SAFETY INSTRUCTIONS

WARNING!

Shearing movement between applicator and dispensing edge! Risk of crushing of the fingers between applicator and dispensing edge and between the moving parts of the applicator!

- During operation: Keep your hands away from the applicator!
- ▶ Operate the applicator only when it is firmly installed on the printer.
- ► Before starting and work on the applicator, switch off the printer and remove the mains plug (e.g. installing or cleaning the applicator)

CAUTION!

Risk of damage to the applicator!

▶ Do not use the applicator as a carrying handle for the printer.



The safety instructions above apply in particular to the applicators LTSA and LTMA. For safe operation of the printer XLP 504 with connected applicator LTSA, respectively XLP 514 with connected applicator LTMA, it is essential to also read and observe the safety instructions in the Operating manual of the printer.



WARNING SYMBOLS ON THE MACHINE

CAUTION!

Warning symbols on the machine provide important information for the operating personnel.

- ► Do not remove warning symbols.
- Replace missing or illegible warning symbols.



Fig. 1: Warning signs on LTSA/LTMA.

Warning symbol	Meaning	Order No.
	The warning symbol "Danger of crushing" warns of dangerous movements of the device that could lead to crushing.	A103530
	The "Read manual" symbol prompts the user to read the Operating manual.	A5331

Table 2: Meaning of the warning symbols.



Product description

INTENDED USE

The Applicator LTSA is an additional device for XLP 504 label printers from NOVEXX Solutions.

The Applicator LTMA is an additional device for XLP 514 or XLP 604 label printers of the same manufacturer.

The applicator takes over self-adhesive labels from the printer's dispensing unit and applies them to moving or stationary products.

The applicator is bolted to the printer by means of a rigid connecting plate. It requires no separate power supply; it is connected to the printer by means of a plug connector and is supplied with power via the printer.

The controller of the applicator is integrated into the firmware of the printer. The application process is triggered by one of the following 4 possibilities:

- Press a button on the printer operation panel
- Easy Plug immediate command (#!D) at the data interface
- Press an optional foot switch (connected to the printer)
- External start signal received via the optional signal interface (e.g. from a product sensor)

Working position: The LTSA/LTMA is an attachment for the above named tabletop printers. The application direction is therefore vertically from top to bottom.

Any other type of or more extensive application will be considered non-intended use. This includes in particular installation of the printers with applicator in any other than the working position described above.

NOVEXX Solutions assumes no liability for damage resulting from any form of non-intended use of the printer.



Fig. 2: Semi-automatic operation of the LTSA/LTMA on a tabletop. The products are positioned by hand, the application process is triggered via a switch (e.g. foot switch).





Fig. 3: Automatic operation of the LTSA/LTMA on a conveyor. The application process is triggered by a start sensor (e.g. light barrier).

DESIGNATION & APPEARENCE

- LTSA stands for Light Touch Stepper Applicator (available for XLP 504)
- LTMA stands for Light Touch Motor Applicator (available for XLP 514 and XLP 604)
- *Light Touch* means that the label is only pressed on lightly because the applicator immediately starts its return stroke as soon as it contacts the product. This allows products with varying heights to be labelled.
- *Stepper* means that the applicator is driven by a stepper motor.

CAUTION! Danger of malfunction or no function at all due to confusion of applicator versions

► Do not mix up the applicator versions.

Distinguishing features of the 3 applicator versions:

Applicator version	Feature 1	Feature 2	
LTSA for XLP 504		Laterally offset adapter plate	
LTMA for XLP 514	Marking on the		
LTMA for XLP 604	rating plate	Flat adapter plate	





Fig. 4: Elements of the LTSA/LTMA.

ltem	Description
1	Adapter plate
2	Stepper motor
3	Fan
4	Connector cable
5	Fan cover
6	Bellows
7	Pressure plate
8	Rating plate

FUNCTIONALITY

The LTSA/LTMA waits in home position in front of the dispensing edge and draws the label onto the foam pad on its underside as soon as it has been dispensed. The vacuum necessary for this is generated by a fan.

After the start signal, the LTSA/LTMA moves its pressure plate down until it contacts a resistance (product), applies the label firmly to the product and immediately starts its return stroke. This automatic reversing function ("Light Touch") allows products with different heights to be labelled. Any minor unevenness in the product surface is compensated by the foam pad of the applicator.



TECHNICAL DATA

Type of material	Self-adhesive labels		
Label size (W x L)	min: 30 x 30 mm max: 80 x 80 mm		
Stroke	max. 190 mm		
Minimum required stroke (distance between home position and product contact)	30 mm		
Application speed	max. 50 labels/minute		
Product speed	max. 35 m/min		
Application angle	90° ± 3°		
Application direction	From top to bottom		
Application precision	± 1 mm (on non-moving products)		
Application force	10 N (with 90° application angle)		
Air current source	Blowers		
Weight	3.2 kg		
Dimensions (W x H x D)	218 x 391 x 120 mm		
Noise level	< 70 dB(A)		
Ambient conditions	Closed rooms		
	Working temperature: 5-40°C		
	Storage temperature: 0-70°C		
	Relative humidity: 30-80%, no water condensation		





Fig. 5: Measures of the LTSA. (Difference LTMA: motor length = 68 mm instead of 79 mm).



SYSTEM REQUIREMENTS XLP 504 WITH LTSA

The XLP 504 must be equipped not only with the necessary firmware version, but also with a few special parts in order to be able to be operated together with a LTSA. This "XLP 504 for LTSA" can be ordered ready for operation or retrofitted.

Necessary firmware version

7.75

Necessary parts

The following parts must be available for operation of a XLP 504 with LTSA:

ltem	Name	Note
А	Applicator LTSA	
В	Enclosure part	
С	Dispensing edge	
D	Sub-D cable harness	Different part than in XLP 504 "Peripheral"
E	Internal rewinder	
F	BLDC output stage	
G	M5A output stage	Different part than in XLP 504 "Peripheral"; minimum required firmware version for output stage: 4.48



Fig. 6: The parts marked in colour are required for operation of a XLP 504 with LTSA (blue = included in retrofit kit LTSA).



Retrofit/conversion kits for the XLP 504

(Output) printer	Rewinder retrofit kit	Conversion kit LTSA	Remaining parts
XLP 504 "Basic"	N100522 ^[1]		Enclosure part
XLP 504 "Peripheral"	N100524 ^[1]		M4A output stage, wiring harness, enclosure part
XLP 504 "Basic" with rewinder			Enclosure part
XLP 504 "Peripheral" with rewinder		N101196	M4A output stage, wiring harness, enclosure part
XLP 504 "Basic" with rewinder & dispenser			Dispensing edge, enclosure part
XLP 504 "Peripheral" with rewinder & dispenser			M4A output stage, wiring harness, dispensing edge, enclosure part

The most economical solution is to retrofit a "XLP 504 basic" or "XLP 504 basic with rewinder", as then less parts are left over after retrofitting.

¹ ATTENTION! - If both kits are retrofitted, install the cable harness from the "conversion kit LTSA" directly!



SYSTEM REQUIREMENTS XLP 514 WITH LTMA

The XLP 514 must be equipped not only with the necessary firmware version, but also with a few special parts in order to be able to be operated together with a LTMA. This "XLP 514 for LTMA" can be ordered ready for operation or retrofitted.

Necessary firmware version

MAR-V3.0

Necessary parts

The following parts must be available for operation of a XLP 514 with LTMA:

ltem	Name
А	Applicator LTMA
В	Enclosure part
С	Dispensing edge
D	Sub-D cable harness
E	Internal rewinder
F	BLDC output stage
G	Stepper motor output stage



Fig. 7: The parts marked in colour are required for operation of a XLP 514 with LTMA (blue = included in retrofit kit LTMA).



Retrofit/conversion kits for the XLP 514

(Output) printer	Rewinder retrofit kit	Conversion kit LTMA	Remaining parts
XLP 514 "Basic"	N102922		Enclosure part
XLP 514 "Peripheral"	N102924		Stepper motor output stage, wiring harness, enclosure part
XLP 514 "Basic" with rewinder			Enclosure part
XLP 514 "Peripheral" with rewinder		N103133	Stepper motor output stage, wiring harness, enclosure part
XLP 514 "Basic" with rewinder & dispenser			Dispensing edge, enclosure part
XLP 514 "Peripheral" with rewinder & dispenser			Stepper motor output stage, wiring harness, dispensing edge, enclosure part

The most economical solution is to retrofit a XLP 514 "Basic" or XLP 514 "Basic" with rewinder, as then less parts are left over after retrofitting.



SYSTEM REQUIREMENTS XLP 604 WITH LTMA

Necessary firmware version

BEL-V4.0

Necessary parts

The following parts must be available for operation of a XLP 604 with LTMA:

ltem	Name
А	Applicator LTMA
В	Dispensing edge type A
С	Sub-D cable harness
D	Stepper motor output stage
E	BLDC output stage
F	Internal rewinder

These requirements are fulfilled by the printer version XLP 604 "Peripheral" with the option "Dispenser type A".



Retrofit kit "Dispenser A" for the XLP 604 "Peripheral": N103521

Fig. 8: The parts marked in colour are required for operation of a XLP 604 with LTMA..



Commissioning

XLP 504: INSTALLING CONVERSION KIT LTSA

Describes how a XLP 504 "Basic" with rewinder is converted into a XLP 504 for LTSA by installing the "conversion kit LTSA".



WARNING!

This machine operates at mains voltage. Contacting electrically live components can cause lethal electrical shocks and burns!

► Only authorised technicians who are familiar with the associated hazards are permitted to carry out conversion work on the printer!

► After assembly, check the machine according to the applicable regulations of the relevant country (for Germany: DIN VDE 701-702 "Recurrent test and test after repair and modification of electrical equipment").

Before you begin

Printer: XLP 504 "Basic" with rewinder

Conversion kit LTSA (N101196)

Tools:

- Torx screwdriver T10, T20
- Open-ended spanner, size 5

Procedure

 Replace enclosure part (1) with enclosure part (2). (4 screws Torx DG 40 x 10)





2. Replace sub-D cable harness:

This step is only necessary if the right cable harness (N101134) was not already installed during retrofitting of the rewinder.

- a) Remove the motor (1).
- b) Replace sub-D cable harness (2).
- c) Install the motor.

For further details, see Service manual XLP 50x, chapter "Service mechanics" > "Internal rewinder / dispenser" > "Retrofitting the internal rewinder" > "Installing the cable harness".



 Install output stage board M5A. (2 screws Torx DG 40 x 10)

Make sure that the jumper is in the correct position (see ill.).





4. Connect sub-D cable harness to the output stage board M5A as shown in the table:

Connect cable with mark	to connector	on printed circuit board	
motor	J3 motor	M5A output stage	
sensor 1	J4 sensor 1	woA output stage	
aux	CN910 aux	CPU Board	
power	CN1202	CF 0 Doard	

For further details, see Service manual XLP 50x, chapter "Appendix" > "Wiring diagrams" > "XLP 504 peripheral".

5. Connect ribbon cable (D) to CPU board (B, CN602) and the two output stages (A, E). Fit hinged ferrite core (C) to the cable as illustrated.



Installing the dispensing edge.
 (2 screws Torx M3 x 6)



7. Close the printer enclosure again.



XLP 514: INSTALLING CONVERSION KIT LTMA

Describes how a XLP 504 "Basic" with rewinder is converted into a XLP 514 for LTMA by installing the "conversion kit LTMA".



WARNING!

This machine operates at mains voltage. Contacting electrically live components can cause lethal electrical shocks and burns!

► Only authorised technicians who are familiar with the associated hazards are permitted to carry out conversion work on the printer!

► After assembly, check the machine according to the applicable regulations of the relevant country (for Germany: DIN VDE 701-702 "Recurrent test and test after repair and modification of electrical equipment").

Before you begin

Printer: XLP 514 "Basic" with rewinder

Conversion kit LTMA (N103133)

Tools:

- Torx screwdriver T10, T20
- Open-ended spanner, size 5

Procedure

 Replace enclosure part (1) with enclosure part (2). (4 screws Torx DG 40 x 10)





- 2. (Optional) Install sub-D cable harness (if not yet done):
 - a) Remove the motor (1).
 - b) Replace sub-D cable harness (2).
 - c) Install the motor.

For further details, see Service manual XLP 51x, chapter "Appendix" > "Internal rewinder / dispenser" > "Retrofitting from Basic to Peripheral".



3. Screw the stepper motor output stage board to the printer base with the supplied screws (A, 2x M4x8) as shown.





- 0 18 1 0008 . Pressure lever -•] E CPL =1 1 Tu (h C 隆 0 1 200 B Đ 000 ۰Ô 0000
- 4. Connect sub-D cable harness according to the illustration:

- For a complete wiring diagram, see Service manual XLP 51x, chapter "Electronics Description" > "Wiring diagram".
- 5. Install the dispensing edge.

(2 screws Torx M3 x 6)



6. Close the printer enclosure again.



XLP 504/XLP 514: INSTALLING LTSA/LTMA

Describes how the LTSA is installed on the "XLP 504 for LTSA" and the LTMA is installed on the "XLP 514 for LTMA".

Before you begin

- XLP 504 for LTSA or XLP 514 for LTMA is available
- LTSA or LTMA is available

Tool:

- Hex socket driver 3 mm
- Torx screwdriver Tx20

Procedure

- 1. (Optional) If present, unscrew cover (1) of the mounting flange.
- 2. (Optional) If present, unscrew enclosure part (2) at front bottom.



3. LTSA/LTMA bolt with adapter plate (2) to the flange of the printer. Use the enclosed 2 screws M5 x 16.



4. Connect sub-D connector (3) to the printer.



XLP 604: INSTALLING LTMA

Describes how the LTMA is installed on the XLP 604 Dispenser.

Before you begin

- XLP 604 Dispenser A is available
- LTMA is available

Tool:

• Hex socket driver 3 mm

Procedure

1. (Optional) If present, unscrew cover of the mounting flange:



2. LTSA/LTMA bolt with adapter plate to the flange of the printer. Use the enclosed 2 screws M5 x 16 (A).



3. Connect the Sub-D connector (picture above, B) to the printer.



SETTINGS IN THE PARAMETER MENU

Describes the settings necessary in the parameter menu of the printer for operation of the applicator.

XLP 504	See chapter Overview of parameter settings XLP 504 with LTSA on page 25
XLP 514	See chapter Overview of parameter settings XLP 514 with LTMA on page 26
XLP 604	See chapter Overview of parameter settings XLP 604 with LTMA on page 27
All	Setting the dispensing position (LTSA/LTMA) on page 28

Overview of parameter settings XLP 504 with LTSA

As soon as "LTSA" is selected as peripheral device, the submenus Options > Dispenser and Options > LTSA with parameters for setting the dispensing and applicator functions are also displayed.

Submenu	Parameter	Setting	Mandatory
Options	External signal	Singlestart	Х
Options > Selection	Periph. device	LTSA	Х
Options > I/O Board	Start print mode ^[2]	"Pulse rising" or "Pulse falling"	Х
Options > Dispenser	Start source	Foot switch	Х
	Dispenseposition	0 mm	
	Dispense Mode	Real 1:1 mode	Х
	Application mode	Immediate mode	
Options > LTSA	Apply mode	After start sig.	
	Stroke length	190 mm	
	Appl. waitpos.	0 mm	
	Applicator speed	350 mm/s	
	Restart delay	0 ms	

The submenu Options > I/O Board appears only if the optional I/O board is installed.

Table 3: List of the most important parameters for applicator operation. The parameters marked "Mandatory" must be set as shown in order that the applicator functions. The settings for the other parameters are given as recommendations and can be changed, depending on the application.

Further parameters for integration of the printer into an application with product conveyor and product sensor are available in submenu "Dispenser". In addition, the optional signal interface (I/O board) is necessary for automatic applications for the processing of external start signals.

For further information on parameter settings, refer to the Operating manual XLP 50x, chapter "Parameter menu".

² Only with installed I/O board (option). This parameter also influences a connected foot switch.



Overview of parameter settings XLP 514 with LTMA

As soon as "LTMA" is selected as peripheral device, the submenus Options > Dispenser and Options > LTMA with parameters for setting the dispensing and applicator functions are also displayed.

The submenu Options > Basic I/O Board appears only if the optional BasicIO board is installed.

Submenu	Parameter	Setting	Mandatory
Options	External signal	Singlestart	Х
Options > Selection	Periph. device	LTMA	Х
Options > Basic I/O Board	Start print mode ^[3]	"Pulse rising" or "Pulse falling"	Х
Options > Dispenser	Start source	Foot switch	Х
	Dispenseposition	0 mm	
	Dispense Mode	Real 1:1 mode	Х
	Application mode	Immediate mode	
Options > LTMA	Apply mode	After start sig.	
	Stroke length	190 mm	
	Appl. waitpos.	0 mm	
	Applicator speed	350 mm/s	
	Restart delay	0 ms	

Table 4: List of the most important parameters for applicator operation. The parameters marked "Mandatory" must be set as shown in order that the applicator functions. The settings for the other parameters are given as recommendations and can be changed, depending on the application.

Further parameters for integration of the printer into an application with product conveyor and product sensor are available in submenu "Dispenser". In addition, the optional signal interface (BasicIO board) is necessary for automatic applications for the processing of external start signals.

For further information on parameter settings, refer to the Operating manual XLP 51x, chapter "Parameter menu".

³ Only with installed BasicIO board (option). This parameter also influences a connected foot switch.



Overview of parameter settings XLP 604 with LTMA

Activating the applicator:

▶ Options > Selection > Periph. device = "LTMA".

As soon as "LTMA" is selected as peripheral device, the submenus Options > Dispenser and Options > LTMA with parameters for setting the dispensing and applicator functions are also displayed.

The submenu Options > BasicIO only appears with the BasicIO board installed (option), which is a prerequisite for operating the LTMA.

▶ Set the parameters according to the table:

Submenu	Parameter	Setting	Manda- tory	De- fault
Options > BasicIO > Start Sensor	Start signal	Singlestart	Х	Х
Options > Selection	Periph. device	LTMA	Х	
Options > Dispenser >	Start print mode	"Pulse rising" or "Pulse falling"	Х	Х
Start signal	Start source	Foot switch	Х	
	Application mode	Immediate mode		Х
Options > Dispenser	Dispense Mode	Real 1:1 mode	Х	Х
	Dispenseposition	0 mm		
	Dispensing edge	Short	Х	Х
	Apply mode	After start sig.		Х
Options > LTMA	Stroke length	190 mm		Х
	Appl. waitpos.	0 mm		Х
	Applicator speed	350 mm/s		Х
	Restart delay	0 ms		Х

Table 5: List of the most important parameters for applicator operation. The parameters marked "Mandatory" must be set as shown in order that the applicator functions. The settings for the other parameters are given as recommendations and can be changed, depending on the application.

Further parameters for integration of the printer into an application with product conveyor and product sensor are available in submenu "Dispenser". In addition, the optional signal interface (BasicIO board) is necessary for automatic applications for the processing of external start signals.

For further information on parameter settings, refer to the Operating manual XLP 60x, chapter "Parameter menu".

Deactivating the applicator:

▶ Options > Selection > Periph. device = "None".

XLP 60x without ribbon saving option from firmware version BEL-V6.0 onwards:

After deactivating a peripheral device (Options > Selection > Periph. device = "None"), the stepper motor output stage must be reassigned its function. The following dialog appears:





► Select "Peripheral" and confirm with key 4.

Setting the dispensing position (LTSA/LTMA)

For operation of the LTSA/LTMA, the dispensing position should be set so that the label is just dispensed and no longer adheres to the backing material. Advancing of the backing material too far can result in threads of the adhesive pulling the label down.

Setting:

▶ Set parameter Options > Dispenser > Dispenseposition to the desired value.



Fig. 9: Schematic view of the dispensing position.

For further details, refer to

- for XLP 50x: Operating manual XLP 50x or Service manual XLP 50x, chapter "Parameter menu"
- für XLP 51x: Service manual XLP 51x, chapter "Product description" > "Parameter menu".



SETTING THE APPLICATOR HOME POSITION



WARNING!

Risk of crushing between the applicator and dispensing edge and between the moving parts of the applicator!

Carry out adjustments only with the printer switched off.

► Hold or fix the applicator foot in extended position, otherwise it will fly back at high speed into the home position - Risk of crushing!

During trial operation: Keep your hands away from the applicator!

Before you begin

- One of the 3 possible printer/applicator combinations is present:
 - XLP 504 with LTSA
 - XLP 514 with LTMA
 - XLP 604 with LTMA
- The settings have been carried out in the parameter menu of the printer (see chapter "Settings in the parameter menu" on page 25)

About this task

In order for the labels to slide smoothly onto the applicator pressure plate after dispensing, the home position of the applicator pressure plate must be checked and adjusted, if necessary, after installation of the LTSA/LTMA. When viewed from the side, the pressure plate must be slightly above the dispensed label (distance B) and slightly ahead of the dispensing edge (distance A).



Fig. 10: Setting the home position of the pressure plate (1). A = Horizontal distance (setpoint: 1 mm), B = Vertical distance (setpoint: 0.5 mm).

Triggering the applicator without printing/dispensing: press the key below the _____ icon.

Procedure

1. Switch on printer.

After booting of the printer and initialisation of the applicator (brief up-and-down movement), the pressure plate is in home position.



2. Check the position of the pressure plate (1) relative to the dispensing edge (2). If adjustment is necessary, determine and note the necessary adjustment distance (horizontal and vertical).

If necessary, carry out the adjustment as follows:

- 3. Switch off the printer.
- 4. Carefully loosen the bellows (3) at the upper end (Velcro fastener).
- Full the applicator foot down so that the two motion links (A and B) are accessible.
 Hold or fix the applicator foot in extended position, otherwise it will fly back at high speed into the home position!

Adjusting the horizontal position:

6. Unscrew motion link (A), adjust according to the table and screw tight again.

Moving motion link A towards	> moves the pressure plate towards
top	front (distance A becomes larger)
bottom	rear (distance A becomes smaller)

Adjusting the vertical position:

7. Unscrew motion link (B), adjust according to the table and screw tight again.

Moving motion link B towards	> moves the pressure plate towards
top	top
bottom	bottom

- 8. Switch on printer.
- **9.** After initialisation of the applicator, check the home position. If necessary, repeat steps 3 and 9 until the home position is correctly adjusted.
 - In home position , the applicator must not reach the upper limit!

- **10.** Secure the bellows again.
- **11.** Switch on the printer and apply a test label.



Operation / Malfunctions / Cleaning

OPERATION

The LTSA/ LTMA is ready for operation when it has been installed, connected and activated. The label dispensing process can be started from one of the following sources as soon as a print job has been transmitted and interpreted:

- Press a button on the printer operation panel
- · Easy Plug immediate command (#!D) at the data interface
- · Press an optional foot switch (connected to the printer)
- External start signal received via the optional signal interface (e.g. from a product sensor)

Manual starting signal by pressing a button

- 1. Switch to the "Home" display.
- 2. Press the button under the symbol 1.

A label from the print job is printed, dispensed and applied.

The last label of a print job can only be triggered by a start signal, not by pressing the apply button at the operating panel.

Automatic start signal at the signal interface

When a start signal from an external signal source^[4] is received at the signal input of the optional I/O board, a label from the print job is printed, dispensed and applied.



For further details of the connection configuration, refer to ...

EXPERTS • XLP 50x

- Service manual, chapter "Service Electronics" > "I/O board" > "Signal interface" > "Wiring of signal inputs"
- User manual, chapter "Special Applications" > "Printing with start signal"
- XLP 51x/XLP 60x
 - Service manual, chapter "Electronics Description" > "Boards" > "BasicIO"

⁴ e. g. from the optional foot switch



REPLACING THE PRESSURE PLATE

About this task

When the foam pad on the pressure plate has become so worn that the function of the applicator is impaired, the pressure plate has to be replaced.

Application of labels to moving products places a greater burden on the pressure plate than application to stationary products.

Procedure

- 1. Switch off the printer.
- 2. Push pressure plate (1) forwards out of the applicator foot.



3. Insert a new pressure plate. Item no.: A4487



REMEDYING MALFUNCTIONS

Status messages

Malfunctions in the applicator generally have one of the following causes:

- The applicator is prevented from moving
- The sensors that limit the movement of the applicator are defective, soiled or not correctly connected
- The printer is not correctly adjusted

Status message	Cause	Measure
5200 Home position	The applicator has not reached its home position within the assigned time period.	 For all status messages: ▶ Check whether the applicator can move unhindered. If necessary, remove
5201 Touch down	The applicator has not reached the product (touch down position) within the set stroke length ^[5] .	any obstacles. EXPERTS ► Check whether the cable(s) is/ are correctly connected.
5203 Touch down sens.	The touchdown sensor(s) was/ were already actuated before the application process.	 EXPERTS Check whether the sensor(s) is/are soiled. EXPERTS Check whether the sensor(s) is/are defective.
		 For 5203 Touch down sens.: ▶ Check, if a product was available. ▶ Check, if the applicator has hit the product.

Table 6: Overview: Status messages possibly caused by an applicator malfunction.

⁵ Setable by Options > LTSA > Stroke length



CLEANING

Safety



WARNING!

Shearing movement between applicator and dispensing edge! Risk of crushing of the fingers between applicator and dispensing edge and between the moving parts of the applicator!

▶ Before cleaning the applicator, switch off the printer and remove the mains plug

Cleaning interval

► Clean the machine regularly.

The frequency depends on the following factors:

- · Operating conditions
- Daily operating duration

Cleaning

CAUTION!

Using sharp cleaning materials may cause damage.

► Do not use any cleaning agents or materials that could damage or destroy the paint finish, labelling, type plates, electrical component, etc.

► Do not use any scouring cleaning agents or any cleaning agents that could dissolve plastic.

► Do not use acid or alkaline solutions.

Cleaning agent:

- · Compressed air, vacuum cleaner (if available)
- Methylated spirits (ethanol) or isopropyl alcohol
- To perform:

▶ Blow off dust and abrasion with compressed air or remove using a vacuum cleaner (if compressed air or vacuum cleaner is available)

▶ Dampen a cloth with methylated spirits or isopropyl alcohol and wipe down the machine.



Novexx Solutions GmbH

Ohmstraße 3 85386 Eching Germany

Telephone: +49-8165-925-0 | www.novexx.com