


# PRODUCT DESCRIPTION

## USI Signal Interface





## Content

USI Board .....	1
Application notes .....	1
View .....	2
Connectors .....	3
Signals at the D-Sub 15 connector .....	3
Application of the internal inputs at CN 300 .....	6
Signal description of the internal inputs at CN300 .....	7
Pin assignment jumper block .....	8
Block diagram .....	8
Circuit diagrams for signal inputs .....	9
Circuit diagrams for signal outputs .....	10
Replacing the controller .....	11

## USI Board

### Application notes

- ▣ Not for ALX 73x (PMA)

#### Utilization

The USI (Universal Signal Interface) is an *optional* signal interface for the following machines:

- 64-xx (24 V)
- ALX 92x (5 V or 24 V)

The following machines come with an USI installed as standard:

- DPM (5 V or 24 V)
- PEM (5 V or 24 V)


Article numbers:

- USI 5 V: A2062 (5 V signal voltage)
- USI 24 V: A2345 (24 V signal voltage)

USI-equipped machines can for example control applicators or scanners. The input signals can be used to trigger the print-dispense-process. The output lines signal the operating status - e.g. material or ribbon end - so that the machine can be integrated completely into a system.

#### Compatibility

- ▣ DPM, ALX 92x: USI and AI (Applicator Interface) can not be installed both into the same device.



[1] Version designations on the USI board.

#### Requirements


- ▣ The functionality described in this section is only then fully available, if the following requirements are met:
  - *USI board*: At least A2062-08 (5 V USI) or A2345-09 (24 V USI) or with a higher index number. Displaying the index number: Sticker on the board [1B, C].

- **USI controller:** At least V6-T36 or a later version with a higher V-number. Displaying the version:
  - Sticker on the microcontroller [1A]
  - Parameter menu: SERVICE DATA >> MODULE FW VERS. > USI interface
  - ▣▣▣▣ Controller version *older* than V6-T36: Update is only possible by exchanging the controller (see chapter [Replacing the controller](#) □ on page 11).
  - ▣▣▣▣ Controller version V6-T36 or higher: Update can be done by loading new firmware (same procedure as for printer firmware update, see topic section [Firmware](#) □). Requirement: printer firmware of at least version 5.30 is installed.
- **Printer firmware:** 5.0 or higher. Displaying the firmware version:
  - Parameter menu: SERVICE DATA >> MODULE FW VERS. > System version
  - During powering up the printer
- **Supply cable:** The USI comes with the data cable connected firmly to the board; But the voltage cable has to be ordered separately (article no. A2059)

**Accessories**









**Product sensor:** For connection to the 24 V USI, a completely assembled product sensor with 2 m cable and D-Sub15 connector is available (article no. A2682).

**View**



[2] USI-board (A2345).

## Connectors

Picture	Comp. Diag.	Type on board	Pin assignment on board
	CN100	AMP 640457-4	
	CN101	Cable is soldered to the board	
	CN300		
	VB200		

[Tab. 1] Connectors on the USI board.

## Signals at the D-Sub 15 connector

Pin	Signal	Function
1	GND_EXT	Ground contact
2	5V_EXT (Voltage supply)	<i>JP8 connected:</i> Internal 5 V source can be used via the wire for external sensors. <i>JP8 clear:</i> Wire can be used for an external 5 V source.
3	START_PRINT\ (Input)	The machine starts printing depending on the setting of parameter <i>DP INTER-FACE &gt; Start print mode</i> . Preconditions: Printjob is available (DATA RDY\ low), printer is in online mode, no error messages.
4	FEED\ (Input)	Feeding of the label material as long as the signal is low. Minimum feed quantity: 1 label. The display shows „USI feed“ during feeding. Preconditions for feeding: <ul style="list-style-type: none"> <li>• Offline mode, printing has been stopped or the printer is in USI-paused mode.</li> <li>• Online mode and no print job loaded.</li> </ul>

[Tab. 2] Signal designations and functions of the USI interface.

Pin	Signal	Function
5	PAUSE\ (Input)	<p>A high-low-transition switches the printer into the USI-paused mode. A further high-low-transition switches the printer back into the online mode.</p> <p>If parameter <code>DP INTERFACE &gt; Start print mode</code> is set to <i>Level high active</i> or <i>Level low active</i>, any activating of the PAUSE\ signal stops the printing after the current label.</p> <p>Features:</p> <ul style="list-style-type: none"> <li>• „USI Pause“ is displayed</li> <li>• ERROR\ is activ (low)</li> <li>• If a print job is available: DATA RDY\ is inactive (high)</li> <li>• Start print signals are suppressed</li> <li>• Reprint requests are proceeded after switching into online mode.</li> <li>• Precondition: START PRINT\ inactive (high).</li> </ul>
6	REPRINT\ (Input)	<p>The last printed label is being reprinted as long as REPRINT\ is low. Minimum reprint quantity: 1 label.</p> <p>Preconditions:</p> <ul style="list-style-type: none"> <li>• The label which is ought to be reprinted, must be ready printed and dispensed.</li> <li>• Printer is in online mode.</li> <li>• If a REPRINT\ is triggered while the printer is in USI-pause mode, the reprint will be proceeded as soon as the printer is switched back in on-line mode.</li> <li>• Precondition: START PRINT\ inactive (high).</li> </ul>
7	24V_EXT (Voltage supply)	Voltage supply for external sensors
8	GND_EXT (GND)	Ground contact

[Tab. 2] (Forts.)Signal designations and functions of the USI interface.

Pin	Signal	Function
9	WARNING (Output)	<p><b>Ribbon low warning:</b> The signal is activated (high), if</p> <p>a) DP INTERFACE &gt; Ribbon signal = „On“ and b) The ribbon stock is below the threshold value, which is set in parameter SYSTEM PARAMETER &gt; Foil end warning. After changing the ribbon roll, the signal will be inactivated after a short time.</p> <p><b>Material end warning:</b> The signal is activated (high), if</p> <p>a) DP INTERFACE &gt; Material signal = „On“ and b) The label material stock is below the threshold, which is set by positioning the light barrier. After changing the material roll, the signal will be inactivated.</p> <p>The WARNING output is only then inactivated (low), if ribbon and material both are available in a sufficient amount. If one of both rolls falls below the threshold value, the output switches activ (high). In practice, the more or less eccentric running material roll will trigger the material warning repeatedly, until the roll diameter falls below a certain tolerance zone.</p> <p>This signal is only a warning, what means that the printing goes on.</p> <p><b>Bad Tag warning:</b> The signal is activated (high), if</p> <p>a) DP INTERFACE &gt; USI profile = „Bad Tag“ and b) Reading or writing a RFID tag failed. The signal timing depends on several factors, e. g. the applied read/write unit, the position of the transponder on the label, the number of retries.</p>
10	ERROR\ (Output)	<p>Active (low) in offline mode <i>or</i> if an error occurs: Not active (high) in online mode.</p> <p>During the initialization of the printer, the output is inactive (high)!</p>
11	PRINT_END\ (Output)	<p>The manner in which this output is switched depends on the setting of parameter DP INTERFACE &gt; End print mode.</p> <p>Difference to older versions of printer firmware (below 2.46): The output is now also activated as long as labels are fed.</p> <p>▣▣▣▣ Limitation: This functionality is not available in Batch mode!</p> <p>▣▣▣▣ 64-xx with LTSI applicator mounted (with PLC version 5.0 and higher): PRINT_END\ is not available.</p>
11	HOME_POS\ (Output)	<p>▣▣▣▣ Only valid for 64-xx with LTSI applicator mounted (with PLC version 5.0 and higher):</p> <ul style="list-style-type: none"> <li>• HOME_POS\ replaces PRINT_END\.</li> <li>• HOME_POS\ is active, if the LTSI is in home position (upper limit position)</li> </ul>
12	MEDIA_OUT\ (Output)	<p>Low in case of material end. Additionally activated are:</p> <ul style="list-style-type: none"> <li>• ERROR\ </li> <li>• MACHINE STATUS\ </li> </ul>

[Tab. 2] (Forts.) Signal designations and functions of the USI interface.



Pin	Signal	Function
13	RIBBON_OUT\ (Output)	Low in case of ribbon end. Additionally activated are: <ul style="list-style-type: none"> <li>• ERROR\&lt;</li> <li>• MACHINE STATUS\&lt;</li> </ul>
14	DATA_RDY\ (Output)	<i>Active (low)</i> in online mode, if a printjob is loaded (--> detecting a loaded printjob). If the signal is active, the printer starts to print immediately after arrival of a start signal.  The signal toggles to <i>deactivated</i> , if <ul style="list-style-type: none"> <li>• the print job is done, or</li> <li>• the printer is switched to stopped mode, offline mode or USI-pause mode.</li> </ul>
15	MACHINE STATUS\ (Output)	This output is activated (low), if the printing has been interrupted by a disturbance or an error. Examples are: Pressure roll open, hood open, ribbon- or material end error, start print error or another fault that avoids printing.  The output is also activated during the initialization of the printer.  <ul style="list-style-type: none"> <li>▣ In comparison to ERROR\&lt;, MACHINE STATUS\&lt; is <i>not</i> low if the printer has been switched to offline or pause mode.</li> <li>▣ 64-xx with LTSI applicator mounted (with PLC version 5.0 and higher): MACHINE_STATUS\&lt; is not available.</li> </ul>

[Tab. 2] (Forts.) Signal designations and functions of the USI interface.

### Application of the internal inputs at CN 300

The following parameter settings are required to make the internal inputs useable:

#### PLC

For usage with PLC:

- DP INTERFACE > Interface type = *USI Applicator*
- DP INTERFACE > Internal inputs = *Enabled*

#### OD sensor

For usage with „OD sensor material“:

- DP INTERFACE > Material signal = *Enabled*
- DP INTERFACE > Internal inputs = *Enabled*

If PLC and „OD sensor material“ are ought to be used, all three parameter settings have to be done.

- ▣ To all four inputs applies: The input is inactivated if it is connected to ground potential!

### Signal description of the internal inputs at CN300


Pin	Signal	Signal type	Function
1	OD control material	In	To be applied to the OD control material option. The signal WARNING at pin 9 of the DB 15 is switched activ, if <ul style="list-style-type: none"> <li>• Parameter DP INTERFACE &gt; Material Signal = <i>Activated</i> and</li> <li>• the input is high</li> </ul>
2	Applicator fault home position	In	If one of the inputs is high or makes a low-high-transition, the appropriate status message is displayed at the printer. Additionally, the outputs ERROR\ and MACHINE STATUS\ will be activated (low).
3	Applicator fault touch down	In	
4	PLC ready / fault	In	
5	GND	Ground	GND potential of the internal inputs

[Tab. 3] Signal designations and functions of the internal inputs

**Pin assignment jumper block**


Each signal of the D-Sub connector can be interrupted separately at the jumper block.

- ▣ The voltage and ground wires are through-connected and cannot be interrupted [3]!




[3] Pin assignment jumper block

**Block diagram**



[4] Block diagram of the USI


**Circuit diagrams for signal inputs**



[5] Main circuit for signal inputs (NPN) at the USI interface (here: connecting a start sensor).


**Timing waveform of input signals**

- The following criteria must be matched by the input signals of the USI:
- ▶ Only one signal at a time may be switched active!
  - ▶ The input signals must switch bounce-free!




[6] Examples of timing waveform for the USI inputs.

Universal Signal Interface (USI)



[7] Signal timing - to be met.

Circuit diagrams for signal outputs




[8] Main circuit (NPN) for signal outputs at the USI interface.

Max output current

In the state of delivery (jumper 8 closed, cable A2059 connected), the supply voltages (5 V on pin 2 and 24 V on pin 8) are provided by the USI. The output current is limited:

- Maximum current per output line: 50 mA; all output currents together may not exceed 700 mA.



[9] USI in the state of delivery: The voltage cable is connected, JP 8 is closed.

## External supply



### CAUTION

In previous versions of this document, the external voltage supply of the USI was described.

External voltage supply without external current limiting elements is no longer permitted (risk of fire)<sup>a</sup>.

In case of applications that externally supply voltages, a current limiting element *must* be provided by the system integrator.

Examples of suitable current limiting elements in the supply circuit are:

- Poly fuse with UL 1434 approval  
 24 VDC:  $I_{\text{hold}} = 650 \text{ mA}$ ;  $U_{\text{min}} = 30 \text{ V}$   
 5 VDC:  $I_{\text{hold}} = 650 \text{ mA}$ ;  $U_{\text{min}} = 6 \text{ V}$
- Micro fuse according to IEC EN 60127  
 24 VDC: T 630 mA L 250 V  
 5 VDC: T 630 mA L 250 V

a. Due to an update of EN 60950-1.


## Replacing the controller

A firmware update for controller versions older than V6-T36 can only be done by replacing the controller [10A].

Article number of the controller with the most recent firmware: A3379.

## Version check

Displaying the current controller version: SERVICE DATA > >MODULE FW VERS. > USI interface.



[10] The controller (A) contains the USI firmware.

## Controller replacement

1. Switch the printer off, pull out the mains connector.
2. Open the rear hood.  
 See topic section [Service Mechanics](#) □, section „Housing“, chapter „Rear hood“.
3. Take the controller [10A] out of the socket.
4. Insert the new controller into the socket.  
 ■▶ The dent in the controller housing must show in the pictured direction!



**Novexx Solutions GmbH**  
Ohmstraße 3  
85386 Eching  
Germany  
☎ +49-8165-925-0  
[www.novexx.com](http://www.novexx.com)

**NOVEXX**   
SOLUTIONS